

Model Nr.: 0XAT1219

Alternator Tool Set 13pcs

- Permits easy removal of over running alternator pulley either on or off the vehicle.
- Insert allows alternator shaft to be held while the pulley retainer is removed with the key nut.



Applications:

Alfa Romeo, Audi, BMW, Citroen, Fiat, Mercedes, Mitsubishi, Renault, Seat, Skoda, Vauxhall/Opel, Volvo, VW

Contents:

- Combined Socket Bits: 1/2"Sq Drive; TRX-Star* - T50-33T x 113mm, Spline - M10-33T x 113mm, Spline - M10-33T x 113mm
- Spline Adaptors: 15mm x 33T, 22mm x 33T
- Hex Adaptor: 22 x 28mm
- Round Adaptor: 35mm-4 pin
- Bits: 10mm Hex Drive; TRX-Star* - T40, T50, Spline - M8, M10, Hex - H8, H10

Adaptor: 1/2"Sq Drive x 10mm Hex

Zestaw narzędzi do sprzęgieł alternatora – 13szt.

- Proste w użyciu i przeznaczone do zdejmowania kół i sprzęgieł alternatora
- Przeznaczone do pojazdów:
Alfa Romeo, Audi, BMW, Citroen, Fiat, GM, Mercedes, Mitsubishi, Renault, Seat, Skoda, Volvo, VW
- Zestaw zawiera:
Nasadki trzpieniowe mieszane: 1/2"Sq Drive; TRX-Star* - T50-33T x 113mm, Spline - M10-33T x 113mm, Spline - M10-33T x 113mm
SPLINE adapter: 15mm x 33T, 22mm x 33T
HEX adapter: 22 x 28mm
Adaptory: 35mm-4 pin
Bity: 10mm Hex Drive; TRX-Star* - T40, T50, Spline - M8, M10, Hex - H8, H10
Adaptory dodatkowe: 1/2"Sq Drive x 10mm Hex

Model Nr.: 0XAT1219

Alternator Tool Set 13pcs

- Permits easy removal of over running alternator pulley either on or off the vehicle.
- Insert allows alternator shaft to be held while the pulley retainer is removed with the key nut.



Applications:

Alfa Romeo, Audi, BMW, Citroen, Fiat, Mercedes, Mitsubishi, Renault, Seat, Skoda, Vauxhall/Opel, Volvo, VW

Contents:

- Combined Socket Bits: 1/2"Sq Drive; TRX-Star* - T50-33T x 113mm, Spline - M10-33T x 113mm, Spline - M10-33T x 113mm
- Spline Adaptors: 15mm x 33T, 22mm x 33T
- Hex Adaptor: 22 x 28mm
- Round Adaptor: 35mm-4 pin
- Bits: 10mm Hex Drive; TRX-Star* - T40, T50, Spline - M8, M10, Hex - H8, H10

Adaptor: 1/2"Sq Drive x 10mm Hex

Zestaw narzędzi do sprzęgieł alternatora – 13szt.

- Proste w użyciu i przeznaczone do zdejmowania kół i sprzęgieł alternatora
- Przeznaczone do pojazdów:
Alfa Romeo, Audi, BMW, Citroen, Fiat, GM, Mercedes, Mitsubishi, Renault, Seat, Skoda, Volvo, VW
- Zestaw zawiera:
Nasadki trzpieniowe mieszane: 1/2"Sq Drive; TRX-Star* - T50-33T x 113mm, Spline - M10-33T x 113mm, Spline - M10-33T x 113mm
SPLINE adapter: 15mm x 33T, 22mm x 33T
HEX adapter: 22 x 28mm
Adaptory: 35mm-4 pin
Bity: 10mm Hex Drive; TRX-Star* - T40, T50, Spline - M8, M10, Hex - H8, H10
Adaptory dodatkowe: 1/2"Sq Drive x 10mm Hex