


Anziehvorschrift Zylinderkopf**Tightening Instructions for Cylinder Head****Instructions de serrage pour culasse****Prescripciones de apriete para culatas****240.160**passend für / suitable for
adaptable à / adaptable a**Audi / Bentley****Das Original**Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo233.930
M 10x1,5x134Anziehen/
Tightening/
Serrage/
Apriete
 M10
30 Nm
60 Nm
➤ 90°
➤ 90°

 M6
10 Nm
➤ 90°
Zeichenerklärung / Explanations / Explication / Explicacion

	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
*	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

V8, TFSI, rechts/right

Mot. CEUC, CEUA, CGTA, CTFA, CRDB

CMMC, CMMD, CYCA, CYCB

S6, RS6, S7, RS7, A8, S8

New Continetal, Flying Spur

Elring-Serviceteam

Fon +49 7123 724 799

Fax +49 7123 724 798

service@elring.de

24/01/22

240.160