

ACHTUNG!

CAUTION!

Wichtiger Montagehinweis für die Pro-Kits Audi A5 Coupe (E10-15-010-01-22; -02-22), Audi A5 Cabrio (E10-15-010-03-22; -04-22; -05-22; -06-22) und Audi A5 Sportback (E10-15-010-07-22; -08-22).

Important instruction for installation of the Pro-Kit Audi A5 Coupe (E10-15-010-01-22; -02-22), Audi A5 Convertible (E10-15-010-03-22; -04-22; -05-22; -06-22) and Audi A5 Sportback (E10-15-010-07-22; -08-22).

Zur Gewährleistung der Fahrzeughöhe an der Hinterachse muss, **wenn werkseitig lt. Abbildung 1 oben vorhanden**, die Kunststoffscheibe zwischen Karosserie und Federgummiunterlage lt. Abbildung 2 entfernt werden!

*For verification of the lowering concerning the rear axle it's stringent necessary to remove the plastic disc according to illustration 1 between the car body and the rubber washer, **if serial existent**.*

Weiter sind die Montagehinweise gemäß Werkstatthandbuch zu beachten.

Furthermore the instructions for installation according to the repair manual have to be considered.

Abbildung 1: Serieneinbausituation

illustration 1: serial installation situation



Abbildung 2: Entfernen der Kunststoffscheibe

illustration 2: removing of the plastic disc

