




THE NEXT STEP IN USER FRIENDLINESS

From now on, attaching the oil pan and gasket to the engine block is no longer a two-man job. Simply insert Snap-ups in four corners of the block and slide all parts into place: two small protrusions keep the oil pan and gasket suspended, so you can easily insert the bolts that keep everything together. It's easy. And it makes servicing a whole lot easier.

NEW


AVAILABLE IN TWO SIZES (PACKED PER 4)


31-030627-00 (ref to order) > 6mm




31-030628-00 (ref to order) > 8mm

HOW TO USE






Slide oil pan gasket and oil pan into place over the Goetze Snap-ups



3. Gently insert and tighten bolts to keep oil pan gasket and oil pan in place



4. Replace Goetze Snap-ups with bolts

WATCH THE VIDEO TUTORIAL:











