







CAT-601S Introduction











The CAT-601S is an automatic transmission cleaner and fluid exchanger from LAUNCH.

It is supplied with a comprehensive range of optional adaptors, allowing connection to most transmission units including double clutch and CVT types. With optional database reference, you can easily make the set up. And it also can be connected to the CAT RemoteAPP (optional) to control equipment operations for the main functions.











New Functions



Old oil sample



Online database (optional)



CAT REMOTE (optional)















Introduction:



- Support optional CAT REMOTE extension to control the equipment operations, and support automotive diagnostic and maintenance functions.
- Cycle cleaning with detergent.
- Equivalent exchange with high accuracy.
- Fluid flow automatically recognized
- Fluid level adjustment
- Filter replacement warning.
- Frequently-used vehicle adding and searching list











Components



Name

1	Power switch
2	Tablet drawer
3	Sight indicator of used fluid
4	Detergent Container
5	Power Plug Socket
6	Sight indicator of new fluid




Components



7	Fluid filling port
8	Fluid draining hose
9	Filter / old oil sample
10	Hose winder
11	Control panel
12	Hoses
13	Back wheel
14	Lockable front wheel



Components



Name

15	Gauge of new fluid
16	Gauge of used fluid

|--|

18	Screen

19 Operation button

20 Operation button



Specifications:

Power supply AC110 / AC220V \pm 10% 50Hz / 60Hz

Pump Power 150W

Exchange error range ±100ml

Pump efficiency 2l/min

Fluid tank volume 201

Detergent tank volume 1.000ml

Temperature sensitivity ±1°C

Filter precision 5_{µm}

Noise <70dB

Ambient temperature -10~50°C

Relative humidity <85%













Functions:



- Old oil sampling
- Add detergent
- → Exchange
- → Adjust fluid level
- → Empty new tank
- → Empty old tank
- → System settings
- → Oil temperature and filter status



Functions:

Old oil sampling

Extract sample of the oil from the gearbox e. g. for testing before starting the oil exchange process.

Add detergent

Add detergent to the AT, and the system will automatically start cycle cleaning after the vehicle engine is start.

Exchange

Exchange the vehicle transmission oil, add new oil into the gearbox and automatically drain the old oil to the oil tank. It provide direct input mode and vehicle selection mode.

Adjust fluid level

Support filling or draining fixed transmission oil.

Empty new tank

Emptying the remaining new oil from the new oil tank. Be sure that the two hoses marked with "TO TRANSMISSION" are not connected with the vehicle.

Empty old tank

Emptying the recovered oil from the old oil tank. Be sure that the two hoses marked with "TO TRANSMISSION" are not connected with the vehicle.

System settings

System setting of the equipment, including sensor calibration, select transmission fluid, window backlight switch, date & time, language select, history records, device information, etc.









