

KEYLESS PROTECTOR –an automatic switch of Keyless / SmartKey /Kessy system remote

User's manual:

1. Open the key casing and take the battery out.
2. Carefully place the Keyless Protector clip on the battery matching + to – on the clip and battery. Do not touch with your fingers copper electrodes or battery poles.
3. Insert the battery with clips in the proper place.
4. If the battery with clip does not fit the casing it should be replaced by a thinner one (e.g. CR2032 change for CR2025).
5. In case of necessity stick little square sponge (included) on the clips next to electrical elements on + side so that the clip's electrode adjoins the battery on + side.
6. Close the key casing carefully assuring yourself that the Keyless Protector clip will not be damaged while closing. Pay attention to whether the clip's electrodes are tightly stuck to the battery. Now, the key is protected, the buttons on the remote do not work.

PROPER PLACE FOR THE KEY: Protected key should be placed in a pocket separately from other items like coins, fobs etc. If the key will be stored in a purse/handbag it should be placed in a separate pocket closest to an exterior side of a purse. It is important to avoid contact of the key with any other items. Please, keep in mind that the other spare key left at home is also endangered – protect him with another Keyless Protector.

HOW TO SWITCH THE KEY ON?

Get close to the car and stay still for 1 second. Sturdily clap the pocket (where you placed the key) twice with 1 second interval between the first and the second clap. The key is activated and after ca. 2 seconds it will communicate with Keyless system allowing opening the car and starting the engine. If the time between claps is too short or too long, the key will not be activated and the car will stay locked.

Please, do not clap the key repeatedly. Stay still again for a second and clap the pocket twice in one second interval.

HOW TO SWITCH THE KEY OFF?

Leave the car and shut the door. When you walk away about 20-25 steps the key will get protected. If you leave the key absolutely still it will also cause an automatic protection of the key after 2 minutes.

That is why never leave the key inside the car!

Attention!

Warranty does not cover mechanical damage, therefore it is recommended to mantle and dismantle the Keyless Protector carefully or to commission this to Authorized Point of Sale and Assembly. Remember that there are various methods on car thefts and there is no 100% protection before break-in and robbery.